800i 3-Tier

FEATURES

- Clear & informative graphic display

- Highest grade HEPA and carbon technology

- Automatic electronic flow control - maintains a constant extraction rate even as the filter blocks

- Gas and particle sensors to warn the operator

- Adjustable airflow

SPECIFICATIONS

Voltage	120v	230v
Volume Part Number	080500D	080501D
Vacuum Part Number	080506D	080504D
Wattage	2.4kW	2.4kW
Frequency	50Hz / 60Hz	50Hz / 60Hz
Cabinet Height	1155mm	1155mm
Cabinet Width	571mm	571mm
Cabinet Depth	675mm	675mm
Cabinet Weight	95kg	95kg
Sound Level	60dBa	60dBa
Airflow	800m3/h	800m3/h

INCLUDED AS STANDARD...

FILTERS

Main Filter Code 113650 — **Description** HEPA

Main Filter Code 113651 — **Description** Chemical

Pre-filter Code 111101 — **Description** F8/F9 Labyrinth

Connection kits are available see overleaf for options

Find out more:

🌐 **www.jorlink.com**

✉ **sales@fumefiltration.com**

✉ **sales@jorlink.com**

📞 **(336) 288-1613**

Machine Supplied With • 2 x Main Filters • 1 x Pre-filter • 1 x 4.5m Fixed Power Cable (no plug) • 1 x Manual

OPTIONS

Main Filter

Code:	Description:
113660	HEPA/Twin Chemical
113658	HEPA/Chemical (Cleanroom)
113667	Solvent Lock
113652	HEPA/Chemical

Connection Kits

Hose End Diameter	Hose Length	Purex Inlet Diameter

Code: 120288 | 80mm | 2.3m | 100mm

Connect to 80mm diameter pipe/port

2.0m   0.3m

Code: 100105 | 100mm | 2m | 100mm

Connect to 100mm diameter pipe/port

2.0m

Code: 100107 | 100mm | 3m | 100mm

Connect to 100mm diameter pipe/port

3.0m

Code: 120291 | 100mm | 3m | 100mm

Connect to 100mm diameter pipe/port

3.0m

**Code:** 100172 | 125mm | 3m | 100mm

Connect to 125mm diameter pipe/port

3.0m

Code: 120294 | 150mm | 3.25m | 100mm

Connect to 150mm diameter pipe/port

3.0m

If you do not see a connection kit that fits your machine or pipework, please contact Purex or your representative

Interfacing

Your Machine — 10011010 / 10011010 — Extractor

Interfacing can remotely start the Purex machine when the connected machine starts.

Interfacing can also warn the connected machine when the Purex machine is in alarm.

Take a look through our Interfacing Guide to see our extensive range of options