FUMECUBE MAX

072115 (230v)

072116 (120v)

FEATURES

- VariColour filter blocked warning system

- Highest grade HEPA and carbon technology

- Automatic electronic flow control - maintains a constant extraction rate even as the filter blocks

- Quiet in operation

- Simple to install and easy to relocate

SPECIFICATIONS

Voltage	230v	120v
Wattage	0.32kW	0.32kW
Frequency	50Hz / 60Hz	50Hz / 60Hz
Cabinet Height	493mm	493mm
Cabinet Width	308mm	308mm
Cabinet Depth	330mm	330mm
Cabinet Weight	14kg	14kg
Sound Level	<60dBa	<60dBa
Airflow	170m3/h	170m3/h

INCLUDED AS STANDARD...

FILTERS

Main Filter
Code
MPEF-110507

Description
HEPA/Chemical

Pre-filter
Code
MPEF-111124

Description
F8/F9 Labyrinth

CONNECTION KIT

Connection kit is included see overleaf for options

Find out more:

🌐 **www.jorlink.com**

✉ **sales@fumefiltration.com**

✉ **sales@jorlink.com**

☎ **+1 (336)288-1613**

Machine Supplied With · 1 x Main Filter · 1 x Pre-filter · 1 x Connection Kit · 1 x Power Cable · 1 x Manual

OPTIONS

Main Filter

Code:
MPEF-110504

Description:
Chemical

Connection Kits

Machine + Hose Kit

| Voltage	Part Number
230v	MPE-072140
120V	MPE-072141

3m

Inlet is on rear of cabinet

Includes:
3m x 50mm flexible hose
2 x connecting cuffs

Machine + 38mm Single Arm Kit

Voltage	Part Number
230v	MPE-072142
120V	MPE-072143

2m

Inlet is on rear of cabinet

38mm Single arm kit includes:
1 x 80 - 51mm reducer
1 x Arm Kit (100295) *see below*

Machine + 38mm Dual Arm Kit

Voltage	Part Number
230v	MPE-072144
120V	MPE-072145

2m

Inlet is on rear of cabinet

38mm Dual arm kit includes:
1 x 80 - 51mm dual manifold
2 x Arm Kits (100295) *see below*

MPK-100295

Includes:
1 x 2m x 50mm flexible hose
2 x connecting cuffs
1 x 38mm stainless steel
   flexible arm with valve
1 x 95mm conical cowl
1 x 38mm pen nib
1 x clamped bench bracket

Replacement Arms

Code:	Description:
MPK-120128	38mm x 1.5m flexible stainless steel arm
MPK-120129	38mm x 0.75m flexible stainless steel arm
MPK-120199	38mm x 0.5m flexible stainless steel arm

38mm

Interfacing

Your Machine
10011010
10011010
Extractor

Interfacing can remotely start the Purex machine when the connected machine starts.

Interfacing can also warn the connected machine when the Purex machine is in alarm.

Take a look through our Interfacing Guide to see our extensive range of options